













Microcellular Elastomer Polyurethane (MEP)**MAZDA**


<p>D14UA00E</p> <p>B25D 28 111-U</p> <p>323 SEDAN'95-2000</p> <p>Shock Absorber Bumper (RE)</p>	 <p>B : 1 / C : 55 pcs.</p>	<p>D14UA00F</p> <p>C100 34 111-U</p> <p>323 SEDAN'95-2000</p> <p>Shock Absorber Bumper (FR)</p>	 <p>B : 2 / C : 70 pcs.</p>
<p>D14U64E</p> <p>GA2A 28 111-U</p> <p>CRONOS</p> <p>Shock Absorber Bumper (RE)</p>	 <p>B : 2 / C : 110 pcs.</p>	<p>D14U64F</p> <p>GA2A 34 111-U</p> <p>CRONOS</p> <p>Shock Absorber Bumper (FR)</p>	 <p>B : 2 / C : 110 pcs.</p>
<p>D14UMZ3F</p> <p>BP4K 34 111B-U</p> <p>MAZDA 3</p> <p>Shock Absorber Bumper (FR)</p>	 <p>B : 2 / C : 70 pcs.</p>		
<p>D14UT20E</p> <p>E112 28 1A0-U</p> <p>TRIBUTE,ESCAPE</p> <p>Shock Absorber Bumper (RE)</p>	 <p>B : 2 / C : 40 pcs.</p>	<p>D14UT20F</p> <p>E112 34 111B-U</p> <p>TRIBUTE,ESCAPE</p> <p>Shock Absorber Bumper (FR)</p>	 <p>B : 2 / C : 70 pcs.</p>

MITSUBISHI













<p>M14U06E0</p> <p>MB338684-U</p> <p>E12, E15, E33</p> <p>Shock Absorber Bumper (RE)</p>	 <p>B : 2 / C : 70 pcs.</p>	<p>M14U02F</p> <p>MB303069-U</p> <p>C12, CB1-2</p> <p>Shock Absorber Bumper (FR)</p>	 <p>B : 2 / C : 70 pcs.</p>
<p>M14U28E0</p> <p>MB809285-U</p> <p>CK, CB</p> <p>Shock Absorber Bumper (RE)</p>	 <p>B : 2 / C : 70 pcs.</p>	<p>M14U06F</p> <p>MB349347-U</p> <p>E12,E15,E33,E54</p> <p>Shock Absorber Bumper (FR)</p>	 <p>B : 2 / C : 110 pcs.</p>
<p>M14UNA4E</p> <p>4060A047-U</p> <p>SPACE WAGON NA4</p> <p>Shock Absorber Bumper (RE)</p>	 <p>B : 2 / C : 50 pcs.</p>		

Microcellular Elastomer Polyurethane (MEP)

NISSAN














<p>N14U32FZ</p> <p>54052-4M400-U</p> <p>NEO, N16</p> <p>Shock Absorber Bumper (FR)</p>	 <p>B : 2 / C : 70 pcs.</p>
--	--

HONDA

<p>O14U090E</p> <p>52722-SM4-961-U</p> <p>ACCORD' 90-93</p> <p>Shock Absorber Bumper (RE)</p>	 <p>B : 2 / C : 70 pcs.</p>	<p>O14U090F</p> <p>51722-SM4-003-U</p> <p>ACCORD' 90</p> <p>Shock Absorber Bumper (FR)</p>	 <p>B : 2 / C : 70 pcs.</p>
<p>O14U094E</p> <p>52722-SM4-013-U</p> <p>ACCORD' 90-98</p> <p>Shock Absorber Bumper (RE)</p>	 <p>B : 2 / C : 70 pcs.</p>	<p>O14U094F</p> <p>51722-SV4-004-U</p> <p>ACCORD' 94</p> <p>Shock Absorber Bumper (FR)</p>	 <p>B : 2 / C : 70 pcs.</p>
<p>O14U292E</p> <p>52722-SR3-003-U</p> <p>CIVIC' 92</p> <p>Shock Absorber Bumper (RE)</p>	 <p>B : 2 / C : 70 pcs.</p>	<p>O14U292F</p> <p>51722-SS0-004-U</p> <p>CIVIC' 92-96 PRELUDE</p> <p>Shock Absorber Bumper (FR)</p>	 <p>B : 2 / C : 110 pcs.</p>
<p>O14U2001</p> <p>52722-S5A-004-U</p> <p>CIVIC' 2001</p> <p>Shock Absorber Bumper (RE)</p>	 <p>B : 2 / C : 110 pcs.</p>	<p>O14U296E</p> <p>52722-SN4-003-U</p> <p>CIVIC' 96</p> <p>Shock Absorber Bumper (RE)</p>	 <p>B : 2 / C : 110 pcs.</p>
<p>O14U496E</p> <p>52722-SS0-003-U</p> <p>CRV' 96</p> <p>Shock Absorber Bumper (RE)</p>	 <p>B : 2 / C : 70 pcs.</p>	<p>O14U402</p> <p>52722-S9A-014-U</p> <p>CRV' 2002</p> <p>Shock Absorber Bumper (RE)</p>	 <p>B : 2 / C : 70 pcs.</p>
<p>O14U003E</p> <p>52722-SDA-A01-U</p> <p>ACCORD' 2003</p> <p>Shock Absorber Bumper (RE)</p>	 <p>B : 2 / C : 70 pcs.</p>	<p>O14U40F</p> <p>51722-S10-004-U</p> <p>CRV' 96</p> <p>Shock Absorber Bumper (FR)</p>	 <p>B : 2 / C : 110 pcs.</p>



Microcellular Elastomer Polyurethane (MEP)

TOYOTA





<p>T14U07F</p> <p>48331-20040-U</p> <p>ST150, ST171</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 110 pcs.</p>	<p>T14U08E</p> <p>48341-20120-U</p> <p>ST171</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 70 pcs.</p>
<p>T14U28E</p> <p>48341-12130-U</p> <p>AE101, EE90</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 70 pcs.</p>	
<p>T14U29F</p> <p>48331-12120-U</p> <p>AE101, ST171, ST191</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 110 pcs.</p>	<p>T14U29E</p> <p>48341-12120-U</p> <p>AE101</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>
<p>T14UE121E</p> <p>48341-47010-U</p> <p>ALTIS, ZZE121-122</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 110 pcs.</p>	<p>T14UE121F</p> <p>48331-12210-U</p> <p>ALTIS, ZZE121-122</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>
<p>T14U11E</p> <p>48341-32052-U</p> <p>ST190</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 70 pcs.</p>	<p>T14UC03F</p> <p>48331-33020-U</p> <p>CAMRY, SXV20</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>
<p>T14UW11E</p> <p>48341-32100-U</p> <p>WISH</p> <p>Shock Absorber Bumper (RE)</p>  <p>B : 2 / C : 110 pcs.</p>	<p>T14UW11F</p> <p>48331-68020-U</p> <p>WISH</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 50 pcs.</p>
<p>T14USV41F</p> <p>48331-32090-U</p> <p>SV41</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 70 pcs.</p>	<p>T14UC04F</p> <p>48331-33031-U</p> <p>CAMRY ACV30</p> <p>Shock Absorber Bumper (FR)</p>  <p>B : 2 / C : 50 pcs.</p>

Microcellular Elastomer Polyurethane (MEP)




BENZ

<p>614U0100</p> <p>201-323-2044-U</p> <p>W124</p> <p>Shock Absorber Bumper (FR)</p>	 <p>Rubber Intrade</p> <p>B : 2 / C : 50 pcs.</p>	<p>614U030F</p> <p>1233-230-544-U</p> <p>W123</p> <p>Shock Absorber Bumper (FR)</p>	 <p>Rubber Intrade</p> <p>B : 2 / C : 70 pcs.</p>
---	--	---	--

BMW

<p>B14UE36E</p> <p>3353-1136-395-U</p> <p>E36</p> <p>Shock Absorber Bumper (RE)</p>	 <p>Rubber Intrade</p> <p>B : 2 / C : 50 pcs.</p>	<p>B14UE34E</p> <p>3353-1135-624-U</p> <p>E34</p> <p>Shock Absorber Bumper (RE)</p>	 <p>Rubber Intrade</p> <p>B : 2 / C : 50 pcs.</p>
<p>B14UE30F</p> <p>3133-1124-449-U</p> <p>E30,E34,E36</p> <p>Shock Absorber Bumper (FR)</p>	 <p>Rubber Intrade</p> <p>B : 2 / C : 70 pcs.</p>	<p>B14UE30E</p> <p>3133-1124-573-U</p> <p>E30</p> <p>Shock Absorber Bumper (RE)</p>	 <p>Rubber Intrade</p> <p>B : 2 / C : 70 pcs.</p>

VOLK SWAGEN

<p>W14U0100E</p> <p>191 512 131B-U</p> <p>VENTO VGP96</p> <p>Shock Absorber Bumper (RE)</p>	 <p>Rubber Intrade</p> <p>B : 2 / C : 50 pcs.</p>	<p>W14U0100F</p> <p>357 412 303-U</p> <p>VENTO VGP96</p> <p>Shock Absorber Bumper (FR)</p>	 <p>Rubber Intrade</p> <p>B : 2 / C : 70 pcs.</p>
<p>W14U02TLE</p> <p>333 512 131B-U</p> <p>VGP 96 (PASSAT ,TL)</p> <p>Shock Absorber Bumper (RE)</p>	 <p>Rubber Intrade</p> <p>B : 2 / C : 70 pcs.</p>		